Installation and Operation Instructions





Specification

| Size | : 236x80x37mm |
|-------------------|-------------------|
| Scene Light Power | : 48W |
| Raw Lumen | : 4500LM & 1800LM |
| Scene Light Angle | : Down 45° |
| Waterproof | : IP6K9K |
| Voltage | : 10-30V |
| | |

| ECE Approval | : | ECE R10, ECE R23 |
|-------------------------|---|-----------------------------|
| Other Approval | : | CE, CA, CISPR 25 Class 4 |
| Housing Material | : | Aluminium Housing, PC Cover |
| Mounting | : | Screw Mount |
| Cable | : | 0.3M cable |
| Gasket | : | Rubber |
| | | |

Wiring Instruciton

| Scene Light Positive Red | (100% brightness, 4500 raw lumen) |
|--------------------------------|---|
| Reversing Light Positive Yello | (40% brightness, 1800 raw lumen, reversing light) |
| Negative Ground ——— Blac | (|

Mounting Assembly





- Only a qualified auto-electrician should install this product. Do Not install this product if unsure.
- Failure to use specified installation parts or hardware will void the product warranty.
- For this product to operate at optimum efficiency, a good electrical connection to groun d must be made.
- Do not install and/or operate this safety product unless you have read and understand the safety information contained in this manual.

IMPORTANT! THIS UNIT IS A SAFETY DEVICE, AND IT MUST BE CONNECTED TO ITS OWN SEPARATE, FUSED POWER POINT TO ASSURE ITS CONTINUED OPERATION WHEN ANY OTHER ELECTRICAL ACCESSORY FAIL.